



## Attention All Drivers:

---

It is imperative to not leave vehicles running in the garage longer than absolutely necessary to prevent emissions from building in the bay. These guidelines apply to **ALL vehicles** and **ALL shifts**. Remember to open bay doors and proceed out of the garage bay once the vehicle is started to complete the walk-around inspection.

### Safety Reminders:

- Open at least **one garage door** when a vehicle is running inside the garage. When possible, open multiple doors.
- Perform the air brake test outside. If the air pressure is low when you first arrive at the bus, complete your interior and exterior WAI. Once you are ready to move the vehicle, start the bus to build air pressure. As soon as the air pressure reaches 100 psi move the vehicle outside and perform your air break test, and then complete the rest of your WAI.
- If your vehicle is parked between other vehicles, do all parts of WAI that do not require the vehicle to be running. Do not move other vehicles without Dispatch's permission.

As a courtesy to other operators and BT staff, if you see any one not adhering to the suggestions listed above offer a courteous reminder about these guidelines.