




## Electric Bus Reference Guide & FAQs

### Electric Bus Battery Warning Lights

- **20% -> Yellow Light & “Low SOC”**: Call in if more than ~1 hour of revenue service remaining
- **~12% -> Yellow Light & beeping**: Call in if not about to start DHD
- **~10% -> Red Light & “SOC critical,” & constant alarm**: If not on DHD park at safe location and await instructions
- **5% -> Bus must be on the lot**: As SOC gets very low expect derated power

### Electric Bus Driving Tips

- **Don't hammer on the gas**
- Start slowing down sooner to allow for more regen
- In extreme scenarios cut the Climate control off for DHD or last loop



### Battery Restart on an Electric Bus

- After turning Master Switch to “Stop System” **WAIT TWO MINTES** before turning off the 12V/24V Battery switch

### “Wait to Start” Troubleshoot

- If “Wait to Start” light stays on longer than usual, check the “High Voltage Interlock” Switch
- Switch is located next to the 12V/24V Battery Switch
- Switch should be in the **“ON”** Position- **Photo examples below**

